



WARNING

- 1) Switch off the power supply before installation
- 2) Installation should be done by registered electricians


1




2



3



4



INCOMING SUPPLY ~220-240V / 50Hz TO FITTING



LIVE (Brown or Red) ———— LIVE

EARTH (Green & Yellow) ———— EARTH


NEUTRAL (Blue or Black) ———— NEUTRAL

5

CH	NW	WW	3000K
CH	NW	WW	4000K
CH	NW	WW	6000K




6



7

2528.00026.0196



2528.00027.1696

